

INSTALLING SHUTTER ON VINYL SIDING

1. Place shutter next to window and mark desired location against wall or window.
2. For smaller sizes of shutters use four steel screws at least 1/8" x 2-3/8" in length. For shutter sizes over 55" use six steel screws.
3. Mark and pre-drill holes into shutter before attaching to wall. Use a 1/4" drill bit.
4. With shutter in location against wall, drill through holes in shutter and into the wall surface 2-3/4" deep.
5. Grasp the steel screw support shank and push through the shutter hole and into wall surface.
6. Tap in the screw "gently" with a hammer to snug shutter against siding.
7. Tighten screw. **DO NOT OVERTIGHTEN**, or this may cause the shutter to dimple as well as constricting the movement (expansion I contraction) of the vinyl siding panels due to temperature variations,

