



INSTALLING FASCIA COVER



Drill nail holes in fascia cover slightly larger than nails being used. The first hole should be 4" from the end and approx. 1" from the top (Fig. 10.4). The next hole should be 22" to 24" from the end and 1" from the bottom. Continue drilling alternately every 18" to 20", leaving another 4" at the other end.



Nail through the drilled holes (Fig. 10.5). Do not drive the nails tight. Leave at least 1/32" clearance so that fascia cover "hangs" loosely. For a neater appearance, overlap fascia cover 2" to 3" and remove the bottom flange on the cover being overlapped.

STAIN REMOVAL CHART

STAINS	CLEANERS	PREPARATION	CLEANING PROCEDURES
1. Light oils and greases Heavy grease Caulking compound Wax, Crayon, Asphalt, Tars, etc.	Solvents - Mineral spirits V.M.P. naphtha auto tar remover	Remove excess with plastic or wooding scraper	Use soft cloth to apply mineral spirits. Avoid polishing stained area by using too much pressure. After removing stain, rinse area with water.
2. Inks (marking) Nail polish Paint, Lipstick Gum	Cleaning fluid	Remove e&s with plastic or wood scraper. Chill gum to remove excess.	Use soft cloth to apply cleaning fluid. Avoid polishing stained area by using too much pressure. After removing stain, rinse area with water.
3. Rust stains	oxalic acid Auto radiator cleaner	Make solution of 1 tablespoon oxalic acid crystals to 1 cup warm water	Apply oxalic acid solution with a soft bridle brush, wipe with damp cloth, and then flush with rust-free water. (Use rubber gloves and protect eyes and face).
4. Stubborn stains	Xylene- Lacquer thinner	Try above steps "" 1 thru 3. If they fail 10 remove the stains, then use this procedure.	Dampen a small section of cloth with a touch of xylene, rub vigorously. Do not remove any more material than necessary Rinse area with water when finished.